


FIG. 1

Any action can be initiated by touching the screen.

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

BET 1 TO 5 CREDITS



25 CENT

JACKS OR BETTER

GAME ONE

CREDIT \$10.00

20

10

TOUCH TO PLAY





FIG. 2

Any action can be initiated by touching the screen.

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

BET 1 TO 5 CREDITS ON ALL GAMES



BET 5 CREDITS 25 CENT

JACKS OR BETTER

GAME ONE

CREDIT \$8.75 60

TOUCH DEAL TO PLAY





FIG. 3

Any action can be initiated by touching the screen.

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

**TOUCH CARDS TO HOLD OR CANCEL
ONE PAIR**



BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME ONE

80

CREDIT \$8.75

TOUCH DRAW TO PLAY

**BET ONE
CREDIT**

**PLAY MAX
CREDITS**

DRAW

90

**PLAY MORE
GAMES**

CANCEL

HELP

FIG. 4

Any action can be initiated by touching the screen.

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

BET 1 TO 5 CREDITS ON ALL GAMES

THREE OF A KIND WINNER PAID 15 CREDITS *110*

2 of CLUBS **2 of HEARTS** **Ace of DIAMONDS** **2 of SPADES** **Queen of SPADES**

HELD **HELD**

BET 5 CREDITS 25 CENT JACKS OR BETTER

CREDIT \$11.25 *120* **GAME ONE** *80*

TOUCH DEAL TO PLAY

125 *125* **PLAY MORE GAMES** **BET ONE CREDIT** **PLAY MAX CREDITS** **DEAL**

CANCEL **CASH OUT** **HELP**

FIG. 5

Any action can be initiated by touching the screen.

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

BET 1 TO 5 CREDITS

CARD **CARD** **CARD** **CARD** **CARD**

25 CENT JACKS OR BETTER **GAME ONE**

CREDIT \$10.00 — 20

TOUCH TO PLAY


ONE GAME **TWO GAMES** **THREE GAMES** **130**

HELP


FIG. 6

Any action can be initiated by touching the screen


BET 1 TO 5 CREDITS ON ALL GAMES



25 CENT JACKS OR BETTER GAME THREE /50



25 CENT JACKS OR BETTER GAME TWO /140



BET 5 CREDITS 25 CENT JACKS OR BETTER GAME ONE /135

CREDIT \$8.75

TOUCH TO PLACE BET GAME ONE







FIG. 7

Any action can be initiated by touching the screen




BET 1 TO 5 CREDITS ON ALL GAMES



25 CENT

JACKS OR BETTER

GAME THREE






BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME TWO



BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME ONE

CREDIT \$7.50

TOUCH TO PLACE BET GAME TWO

50



/70



FIG. 8

Any action can be initiated by touching the screen


BET 1 TO 5 CREDITS ON ALL GAMES




BET 5 CREDITS



25 CENT



JACKS OR BETTER




GAME THREE




BET 5 CREDITS




25 CENT



JACKS OR BETTER



GAME TWO




BET 5 CREDITS



25 CENT



JACKS OR BETTER



GAME ONE

CREDIT \$6.25

TOUCH TO PLACE BET GAME THREE

50






180



FIG. 9

Any action can be initiated by touching the screen

TOUCH CARDS TO HOLD OR CANCEL





BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME THREE /50




BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME TWO /40



BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME ONE /35

CREDIT \$6.25 /90

TOUCH DEAL TO PLAY



70

FIG. 10
PAY TABLES

CREDITS WAGERED	1	2	3	4	5
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

25 CENT JACKS OR BETTER **GAME THREE**

CREDITS WAGERED	1	2	3	4	5
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

25 CENT JACKS OR BETTER **GAME TWO**

CREDITS WAGERED	1	2	3	4	5
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

25 CENT JACKS OR BETTER **GAME ONE**



FIG. 11





FIG. 12



Any action can be initiated by touching the screen

TOUCH CARDS TO HOLD OR CANCEL

TWO PAIRS WINNER PAID 10 CREDITS



FULL HOUSE WINNER PAID 45 CREDITS



CREDIT \$20.00 — 190

TOUCH DEAL TO PLAY





FIG. 13

Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES. **2/0****

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5

BET 1 TO 5 CREDITS



25 CENT JACKS OR BETTER "BONUS PAYS"

GAME ONE

CREDIT \$10.00—20

TOUCH TO PLAY

**ONE
GAME**

**TWO
GAMES**

**THREE
GAMES**

220

230

**SEE BONUS
PAYS**

**SEE
PAYS**

HELP

FIG. 14

**PLAYER ELIGIBLE FOR BONES PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**

BONUS PAYS PAY TABLES

TWO OUT OF TWO GAMES

	CREDITS
ROYAL FLUSHES	2000
STRAIGHT FLUSHES	125
FOUR OF A KINDS	60
FULL HOUSES	25
FLUSHES	20
STRAIGHTS	15
THREE OF A KINDS	10
PAIRS	5
JACKS OR BETTER	5

TWO OUT OF THREE GAMES

ROYAL FLUSHES	1000
STRAIGHT FLUSHES	75
FOUR OF A KINDS	30
FULL HOUSES	25
FLUSHES	20
STRAIGHTS	15
THREE OF A KINDS	10
TWO PAIRS	5
JACKS OR BETTER	5

THREE OUT OF THREE GAMES

ROYAL FLUSHES	3000
THREE STRAIGHT FLUSHES	200
FOUR OF A KINDS	40
FULL HOUSES	35
FLUSHES	30
STRAIGHTS	25
THREE OF A KINDS	20
TWO PAIRS	15
JACKS OR BETTER	10


**RETURN TO
GAME**

FIG. 15


Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**

BET 1 TO 5 CREDITS ON ALL GAMES





25 CENT




JACKS OR BETTER "BONUS PAYS"



GAME TWO



BET 5 CREDITS 25 CENT



**JACKS OR BETTER "BONUS PAYS"
GAME ONE**

CREDIT \$8.75

TOUCH TO PLACE BET GAME ONE

50

Bet One Credit

Play Max Credits

Place Bet Game One

160

See Bonus Pays

See Pays

Cancel





Help

FIG. 16

Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**





BET 1 TO 5 CREDITS ON ALL GAMES



BET 5 CREDITS

25 CENT

**JACKS OR BETTER "BONUS PAYS"
GAME TWO**



BET 5 CREDITS

25 CENT

**JACKS OR BETTER "BONUS PAYS"
GAME ONE**

CREDIT \$7.50

TOUCH TO PLACE BET GAME TWO

50

**Bet One
Credit**

**Play Max
Credits**

**Place Bet
Game Two**

170

**See Bonus
Pays**

See Pays

Cancel

Help






7.50 7.50 7.50 7.50 7.50

FIG. 17

Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**

BET 1 TO 5 CREDITS ON ALL GAMES








BET 5 CREDITS

25 CENT

JACKS OR BETTER "BONUS PAYS"

GAME TWO 140



BET 5 CREDITS

25 CENT

JACKS OR BETTER "BONUS PAYS"

GAME ONE 135

CREDIT \$7.50—240

TOUCH DEAL TO PLAY

Bet One Credit

Play Max Credits

Change Bets

DEAL—70

See Bonus Pays

See Pays

Cancel


Help

FIG. 18

Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**


TOUCH CARDS TO HOLD OR CANCEL



BET 5 CREDITS 25 CENT

JACKS OR BETTER "BONUS PAYS"

GAME TWO 140



BET 5 CREDITS 25 CENT

JACKS OR BETTER "BONUS PAYS"

GAME ONE 135

CREDIT \$7.50

TOUCH DRAW TO PLAY




FIG. 19




FIG. 20

DRAW POKER HAND FREQUENCIES

ONE OUT OF ONE GAME

ROYAL FLUSH	40,000.00
STRAIGHT FLUSH	13,333.33
FOUR OF A KIND	434.78
FULL HOUSE	90.09
FLUSH	90.91
STRAIGHT	87.72
THREE OF A KIND	13.77
TWO PAIR	7.94
JACKS OR BETTER	4.67
ALL OTHER HANDS	1.81

TWO OUT OF TWO GAMES

ROYAL FLUSH	1,600,000,000.00
STRAIGHT FLUSH	177,777,777.78
FOUR OF A KIND	189,035.92
FULL HOUSE	8,116.22
FLUSH	8,264.46
STRAIGHT	7,694.68
THREE OF A KIND	189.73
TWO PAIR	62.99
JACKS OR BETTER	21.84
ALL OTHER HANDS	3.29

TWO OUT OF THREE GAMES

ROYAL FLUSH	1,066,666,666.70
STRAIGHT FLUSH	118,518,518.52
FOUR OF A KIND	126,023.95
FULL HOUSE	5,410.81
FLUSH	5,509.64
STRAIGHT	5,129.79
THREE OF A KIND	126.49
TWO PAIR	41.99
JACKS OR BETTER	14.56
ALL OTHER HANDS	2.19

THREE OUT OF THREE GAMES

ROYAL FLUSH	64,000,000,000,000.00
STRAIGHT FLUSH	2,370,369,777,807.41
FOUR OF A KIND	82,189,037.30
FULL HOUSE	731,190.26
FLUSH	751,322.06
STRAIGHT	674,977.33
THREE OF A KIND	2,612.58
TWO PAIR	500.14
JACKS OR BETTER	102.99
ALL OTHER HANDS	5.95


FIG. 21

Any action can be initiated by touching the screen.


**PLAY 5 CREDITS ON BIG MONEY WHILE PLAYING TWO
OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY**

	1st credit	2nd credit	3rd credit	4th credit	5th credit
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5



BET 1 TO 5 CREDITS



25 CENT



JACKS OR BETTER



GAME ONE

CREDIT \$10.00—20

TOUCH TO PLAY

220—



—260



FIG. 22


Any action can be initiated by touching the screen.

**PLAY MAX COINS ON BIG MONEY WHILE PLAYING TWO
OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY**


BET 5 CREDITS

25 CENT \$\$ BIG MONEY \$\$ GAME




BET 1 TO 5 CREDITS ON GAMES ONE & TWO




25 CENT




JACKS OR BETTER




GAME TWO





BET 5 CREDITS



25 CENT



JACKS OR BETTER



GAME ONE

CREDIT \$8.75

TOUCH TO PLACE BET GAME ONE

50



130



FIG. 23






Any action can be initiated by touching the screen.

**PLAY 5 CREDITS ON BIG MONEY WHILE PLAYING TWO
OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY**

BET 5 CREDITS

25 CENT \$\$ BIG MONEY \$\$ GAME

BET 1 TO 5 CREDITS ON GAMES ONE & TWO








BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME TWO



BET 5 CREDITS

25 CENT

JACKS OR BETTER

GAME ONE

CREDIT \$7.50

TOUCH TO PLACE BET GAME TWO

50



145




FIG. 24

Any action can be initiated by touching the screen.

PLAY 5 CREDITS ON BIG MONEY WHILE PLAYING TWO OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY

BET 5 CREDITS

BET 5 CREDITS 25 CENT \$\$ BIG MONEY \$\$ GAME



BET 5 CREDITS





25 CENT



JACKS OR BETTER



GAME TWO




BET 5 CREDITS




25 CENT



JACKS OR BETTER



GAME ONE



CREDIT \$6.25

TOUCH TO PLACE BET ON \$\$ BIG MONEY \$\$

55

**BET'S
CREDITS**

**PLACE BET
BIG MONEY**

DEAL

70

**SEE
PAYS**

**SEE PAYS
BIG MONEY**

CANCEL

HELP

270


FIG. 25

Any action can be initiated by touching the screen.

PLAY 5 CREDITS ON BIG MONEY WHILE PLAYING TWO OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY

BET 5 CREDITS 25 CENT \$\$ BIG MONEY \$\$ GAME

TOUCH CARDS TO HOLD OR CANCEL



CREDIT \$6.25

TOUCH DRAW TO PLAY




FIG. 26




FIG. 27

PLAY 5 CREDITS ON \$\$ BIG MONEY \$\$ WHILE PLAYING TWO OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY.

\$\$ BIG MONEY PAY TABLES \$\$

TWO OUT OF TWO GAMES

	CREDITS
ROYAL FLUSHES	160,000
STRAIGHT FLUSHES	6,250
FOUR OF A KINDS	1,560
FULL HOUSES	200
FLUSHES	90
STRAIGHTS	40
THREE OF A KINDS	30
PAIRS	20
JACKS OR BETTER	15

TWO OUT OF THREE GAMES

ROYAL FLUSHES	53,000
STRAIGHT FLUSHES	2,000
FOUR OF A KINDS	520
FULL HOUSES	60
FLUSHES	30
STRAIGHTS	15
THREE OF A KINDS	10
TWO PAIRS	6
JACKS OR BETTER	5

THREE OUT OF THREE GAMES

ROYAL FLUSHES	6,400,000
THREE STRAIGHT FLUSHES	156,250
FOUR OF A KINDS	19,530
FULL HOUSES	9,100
FLUSHES	2,700
STRAIGHTS	800
THREE OF A KINDS	340
TWO PAIRS	100
JACKS OR BETTER	50


RETURN TO
GAME

FIG. 29


Any action can be initiated by touching the screen.

**PLAYER IS ELIGIBLE FOR BONUS PAYS WHILE PLAYING
MAX COINS ON TWO OR MORE GAMES.**




BET 1 TO 5 CREDITS



BET 5 CREDITS




**\$1.00 JACKS OR BETTER "BONUS PAYS"
GAME TWO**




BET 1 TO 40 CREDITS





BET 20 CREDITS



5 CENT



DEUCES WILD "BONUS PAYS" GAME ONE



CREDIT \$4.00

TOUCH DEAL TO PLAY





FIG. 30





Any action can be initiated by touching the screen.

**PLAY 5 CREDITS ON BIG MONEY WHILE PLAYING TWO
OR MORE GAMES FOR A CHANCE TO WIN REALLY BIG MONEY**

BET 5 CREDITS

BET 5 CREDITS 25 CENT \$\$ BIG MONEY \$\$ GAME

BET 1 TO 5 CREDITS





BET 5 CREDITS

\$1.00

JACKS OR BETTER

GAME TWO

BET 1 TO 40 CREDITS



BET 20 CREDITS

5 CENT

JACKS OR BETTER

GAME ONE

CREDIT \$4.00

TOUCH DEAL TO PLAY



FIG. 31


MACHINE—500

1


Any action can be initiated by touching the screen.

	1st credit	2nd credit	3rd credit	4th credit	5th credit
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5



BET 1 TO 5 CREDITS



25 CENT



JACKS OR BETTER



GAME ONE

CREDIT \$10.00

TOUCH TO PLAY



5/0

FIG. 32

MACHINE






1

Any action can be initiated by touching the screen.

TO PLAY \$BIG MONEY\$ GROUP PLAY
EACH PLAYER(S) MUST WAGER TWO CREDITS TO PLAY

Up to three player(s) may play together.

Select one or two of the eligible machines below to play.



SELECTED

520

25 CENT

BIG MONEY GROUP PLAY

GAME ONE

CREDIT \$10.00

TOUCH TO PLAY



530



FIG. 33

MACHINE

1


Any action can be initiated by touching the screen.

\$BIG MONEY\$ GROUP PLAY "BET TWO CREDIT" — 540


550 — machines 1&2 participating in \$BIG MONEY\$ GROUP PLAY

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5


BET 1 TO 5 CREDITS




25 CENT




CREDIT \$10.00



JACKS OR BETTER



GAME ONE



TOUCH TO PLAY

**BET ONE
CREDIT**

**BET MAX
CREDITS**

**CHANGE
BETS**

DRAW

**SEE
PAYS**

**SEE
BIG MONEY
PAYS**

CANCEL

HELP


FIG. 34

MACHINE—560


Any action can be initiated by touching the screen.

	1st credit	2nd credit	3rd credit	4th credit	5th credit
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5


BET 1 TO 5 CREDITS




25 CENT



JACKS OR BETTER



GAME ONE



CREDIT \$10.00

TOUCH TO PLAY



510

FIG. 35


MACHINE

2


Any action can be initiated by touching the screen.

TO PLAY \$BIG MONEY\$ GROUP PLAY
EACH PLAYER(S) MUST WAGER TWO CREDITS TO PLAY


Up to three player(s) may play together.
Select one or two of the eligible machines below to play.



SELECTED
580



25 CENT



BIG MONEY GROUP PLAY



GAME ONE



CREDIT \$10.00

TOUCH TO PLAY



530



1000-2000-3000-4000

FIG. 36

MACHINE

2


Any action can be initiated by touching the screen.

\$BIG MONEY\$ GROUP PLAY "BET TWO CREDIT" — 540


610 — machines 2&1 participating in \$BIG MONEY\$ GROUP PLAY

	1st coin	2nd coin	3rd coin	4th coin	5th coin
ROYAL FLUSH	250	500	750	1000	4000
STRAIGHT FLUSH	50	100	150	200	250
FOUR OF A KIND	25	50	75	100	125
FULL HOUSE	9	18	27	36	45
FLUSH	6	12	18	24	30
STRAIGHT	4	8	12	16	20
THREE OF A KIND	3	6	9	12	15
TWO PAIR	2	4	6	8	10
JACKS OR BETTER	1	2	3	4	5



BET 1 TO 5 CREDITS



25 CENT



JACKS OR BETTER



GAME ONE

CREDIT \$10.00

TOUCH TO PLAY

**BET ONE
CREDIT**

**BET MAX
CREDITS**

**CHANGE
BETS**

DRAW

**SEE
PAYS**

**SEE
BIG MONEY
PAYS**

CANCEL

HELP